

Clipper Boardinghouse · Ditmar-Koel-Str. 1 · 20459 Hamburg

Manual Nespresso coffee machine

phone +49 40.37 696-0 fax +49 40.37 696-194 cbhm@clipper-boardinghouses.de www.clipper-boardinghouses.de

Installation

Fill the water tank with water and turn the machine on. The buttons with the coffee cups will now start flashing in order for the machine to warm up. The warm-up takes about 1 minute, after which the buttons stop flashing.

Preparation

- 1. Place a coffee cup under the coffee spout.
- 2. Lift the handle until the capsule hole is fully open.
- 3. Place the capsule into the hole, then close it by pressing the handle down.
- 4. Press the coffee button displaying the desired cup size.
- 5. Once brewed, lift the handle to empty the used capsule into the capsule container.

Emptying the capsule container

The container can hold up to 12 empty capsules. Carefully lift the capsule container and drip grid out of the machine. After emptying this, replace it back in its original position.

